Troubleshooting Guide DX2

Confirm that gas pressure


is within minimum and maximum inputs as indicated on the burner

rating plate. Are they ok?

Continued on page below.

NOTICE

Bypassing any switch is intended for testing purposes only. Do not leave switch bypassed during normal operation or the heater's built-in safety mechanisms will be compromised.



Correct problem.

Replace gas valve.

