


# Troubleshooting Guide AVS


\*

NOTICE

Bypassing any switch is intended for testing purposes only. Do not leave switch bypassed during normal operation or the heater's built-in safety mechanisms will be compromised.



Continued from page above.



**Diagnostic Indicator**

LED	MODE
1 Flash	Start up.
2 Flashes	Flame. No call for heat.
3 Flashes	Ignition lockout.
4 Flashes	Valve relay lockout.

